

1 - Unpacking

1. Remove the timber packaging. Leave the unit on the pallet.
2. Open the door of the appliance.
3. Remove the 2 Charcoal Grate, the ashtray and the deflector.
4. Remove the unit from the pallet.

2 - Unclamping the centering ring.

Loosen the nut and remove the nod that makes the centering ring secured to the pan.

Remove and replace the disc with a hole by the plain one (which was in the ashtray)

Lift the unit and remove the centering ring.

3 - Preparation of the centering ring.

Before placing the centering ring on the ground, mount screws and bolt on to the ring as per below:

1. Engage a screw on a bolt by giving a ½ turn.
2. Place this on one of the 5 holes of the ring through the bottom of it.
3. Screw a second nut on the other end.
4. Repeat this operation five times.

4 - Level the centering ring.

1. Place the ring on the floor at the desired location for installation.
2. Place the Allen key No. 8 in the footprint of the screws and remove the top nut. You don't need the top nut anymore.
3. Turn the 5 screws clockwise or anti-clockwise to achieve perfect level and stability. (You may want to use a spirit level for that step).

5 - Before placing the unit on top of the centering ring!

1. Make sure the ball bearings are placed in their slot.
2. Unscrew the nod at the back of the stove bottom plate. The nod has to be slightly higher than the surface of the plate.

6 - Placing the unit on the centering ring.

1. Place the unit on top of ring. Make sure the unit is well centered. The unit should now be easily rotated.
2. Tighten the screw at the back of the bottom plate to slowdown the rotation. You can completely stop the rotation by screwing the nod very tightly.

You can now put back the deflector, the grates and the ashtray in the Unit.